


ASSEMBLY INSTRUCTIONS FOR YOUR ECHO CHANDELIER

IMPORTANT SAFETY INSTRUCTIONS:

- * These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.
- * **WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.**
- * Turn off power at switch before replacing bulbs, making sure fixture has had sufficient time to cool down.
- * **DO NOT** subject the fixture to any shock while lit as shattering of bulbs may result.

ASSEMBLY INSTRUCTIONS:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY AT FUSE BOX/ CIRCUIT BREAKER.
2. Remove parts from carton and discard packing material.
3. Remove mounting plate (B) from canopy (D) by removing screws (E). Set screws (E) aside.
4. Affix mounting plate (B) to ceiling outlet box with mounting screws (C) provided.
5. Measure desired drop for fixture to hang and add/remove extension tubes (I) as needed. Guide wiring through extension tubes before threading tubes together.
TO ADD/REMOVE EXTENSIONS: (Un)Thread the threaded nipple of one extension into/ out of the threaded opening of the next extension. Make sure electrical cord is pulled tight when threading extensions together to prevent damage to the wiring.
6. Connect hang straight (F) to loop (H) with quick link (G).
7. Thread bottom extension tube (I) onto threaded nipple (J).
8. Guide wiring from top extension (I) through loop (H), quick link (G) and hang straight (F), exiting canopy (D). Lift canopy (D) to ceiling outlet box.
9. Make the proper electrical connections described in steps 10-12. A LICENSED ELECTRICIAN IS RECOMMENDED.
10. Attach ground wire from fixture (green or silver in color) to ground wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape.
11. Attach hot wire from fixture (black in color or smooth side of wire) to hot wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape.



12. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape. Carefully push the wire connections back into the ceiling outlet box.
13. Place canopy (D) over mounting plate (B). Thread canopy screws (E) into holes in canopy (D), and mounting plate (B) to secure fixture to ceiling.
14. Place shades (K) onto sockets (L).
15. Insert six (6) 60W MAX. G16.5, candelabra base bulbs into sockets (L).
16. Reconnect main electrical supply from the fuse box/ circuit breaker and test the fixture.

To clean, use soft cloth only. Do not use any chemical or abrasive cleaners.